



CVM Series Monitor			
My screen does not light up. My screen is Dark.			
This is typically the result of a loss of power to the monitor. Areas to look at include: Vehicle power Monitor			
		Yes	No
Step 1	Press the ON/SB button. Did the screen light up?	Done	Go to step 2
Step 2	Turn the brightness and contrast controls all the way clockwise. Did the screen light up?	Done	Go to step 3
Step 3	Do you have a good ground on the monitor black wire and +11 to +32 volts on the monitors red wire?	Go to step 4	Correct wiring and retest
Step 4	Contact your Intec service rep. They may ask you to return your monitor for service.		