



CVD Series			
One or more of my camera positions show a Blue Screen with the words No Signal but other positions work.			
This is the result of a loss of video from the camera position(s) to the display. Areas to look at include: Camera(s) Camera Cable(s) Controller			
		Yes	No
Step 1	Check the connection between the camera and camera cable and controller and camera cable. Make sure it is connected properly. Did this fix you problem?	Done	Go to step 2
Step 2	Unplug one of the camera cables from a working position at the controller and move it to the position(s) that is not working. Does the non working position(s) now show an image? Make sure you've selected the correct position via the remote.	Go to step 3	Go to step 4
Step 3	Place the camera cables back in their original position and move only a working camera to the position(s) that is not working. Do you get an image?	Contact your Intec Service Rep. They may ask you to return your camera for service.	Check the camera cable for damage. It may need to be replaced.
Step 4	Contact your Intec Service Rep. They may ask you to return your controller for service.		